



**1.** Attach plastic feet to all 6 uprights, the narrow part of each slot pointing downwards.

**2.** With another person holding the uprights, place the 1830mm upright to the back and the 915mm to the front. Now tap the side beams in at the required positions for the worktop (top 2 holes) and lower shelf level.

**3.** The face beams for the work top should be positioned in the top two holes of the 915mm upright. Locate the face beams for the undershelf at the same level as the lower side beams.

**4.** Now insert the front to back deck support in the main work station level and the undershelf.  
(2440mm wide workstation comes with 2 deck supports per level)

**5.** Now you can add the 18mm thick shelf to the work top and undershelf level.

**6.** Now position the 903mm uprights on top of the work top ready to tap in the side beams, position side beams as necessary.

**7.** Repeat for the face beams and then add the front to back deck support to both levels.  
(2440mm wide workstation comes with 2 deck supports per level)

**8.** Add the 18mm thick chipboard panels to each shelf level.

**9.** Finally screw the plastic feet of the 903mm uprights down to the worktop with the 3.5 x 17mm chrome screws provided.

### Tools Required

Rubber Mallet, Phillips Screwdriver

### Safety Precaution

**Two competent people** wearing **safety gloves**, **safety shoes** and **protective eyewear** are recommended to undertake the assembly.